


Wall: Timber construction *Airtight on the inside*




Injection hole



- Pull out Sicrall 170
- Measure to the required length
- Tear over the blade



- Sicrall is easy to tear-off at perforation



- Press it on with a hard rubber roller
- Improves instant adhesion and is easy to use



Sicrall® 170

P. 111